










Machine	Explode	Code	Description
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	1		Body Frame
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	2		GN Pan
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	3	AU651	Oil Baffle
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	4		Left Mounting Holder
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	5		Right Mounting Holder
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	6		Top Cover
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	7	AU652	Lower Heating Element
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	8	AU653	Switch
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	9	AS582	UK Power Cord
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	10	AL187	Power Cord Connector
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	11		Heat Reflecting Cover
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	12		Terminal Block
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	13	AU654	Cover Plate
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	14	AU655	Lamp Holder
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	15	AU656	Heating Lamp
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	16		Hexagon Screw
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	17		Bottom Plate
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	18	AK017	Rubber Feet (set 4)
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	19	AU657	Plastic Pipe Plug
Buffalo Countertop Food Warmer with sloped Chip scuttle plate	20	AU658	Rubber Plug