




VOGUE

HC847 Vogue Castors for Vogue St/St Tables (Pack 4)

Assembly Instructions



 **SWL (Safe Working Load) with the Castors Installed: 100Kgs**

UK		Fourth Way, Avonmouth, Bristol, BS11 8TB United Kingdom
Eire	+44 (0)845 146 2887	Unit 9003, Blarney Business Park, Blarney, Co. Cork, Ireland
NL	040 - 2628080	
FR	01 60 34 28 80	

BE-NL	0800-29129	
BE-FR	0800-29229	
DE	0800 - 1860806	
ES	901-100 133	
AU	1300 225 960	15 Badgally Road, Campbelltown, NSW 2560, Australia

